

800W 1.25 Litre Filter Coffee Maker - Black



IG8127

PO Number:

Please read these instructions carefully before use and retain for future reference

Before switching on you appliance

Always check for any damage which may have been caused in transit

CONTENTS

Important Safety Instructions.....	2-4
Appliance Overview	4
Operating Instructions.....	5
Cleaning & maintenance	5-6
Hints for Great Tasting Coffee.....	6
Fuse Replacement.....	6
Trouble Shooting Guide.....	7
Disposal Information.....	8
Igenix Warranty	10-11

SAFETY INSTRUCTIONS


Please read this user manual carefully before using your appliance to ensure proper use and maintenance.

1. This appliance is intended for domestic use; to be used in a household or similar applications such as
 - a. Staff kitchen areas in shops, offices and other working environments;
 - b. By clients in hotels, motels and other residential type environments;
 - c. Bed and breakfast type environments.
2. Do not operate the unit with a damaged cord or plug, after it malfunctions or has been dropped or damaged in any way.
3. All electrical repairs must be carried out by a qualified electrician. Inadequate repairs may result in a major source of danger for the user and invalidate the warranty.
4. Make sure the voltage in your home corresponds to the one shown on the rating label of the appliance.
5. This appliance can be used by children aged from 8 years and above if they have been given supervision or instruction concerning the use of the appliance in a safe way and understand the hazards involved.
6. Cleaning and user maintenance shall not be made by children
7. Keep the appliance and its cord out of reach of children aged less than 8 years.

8. Children shall not play with the appliance.
9. This appliance can be used by persons with reduced physical, sensory or mental capabilities or lack of experience and knowledge if they have been given supervision or instruction concerning use of the appliance in a safe way and understand the hazards involved.
10. Do not let the cord hang over the edge of a table or counter or touch a hot surface.
11. Do not place on or near a hot gas or electric burner or a heated oven.
12. Do not operate the appliance without water to avoid damaging the heat elements.
13. To protect against a fire, electric shock or personal injury, do not immerse cord or electric plug in water or other liquids.
14. Some parts of the appliance are hot when operated - Do not touch the hot surface, use the handle or the buttons.
15. Extreme caution must be used when moving an appliance containing hot water.
16. The use of accessories, which are not recommended by the manufacturer, may result in fire, electric shock or personal injury.
17. Unplug the appliance from the wall socket when not in use and before cleaning. Allow the appliance to cool before cleaning.
18. Do not use the appliance near facilities containing water, such as bath tubs, showers or wash basins.
19. The glass carafe is designed for use with this appliance. It cannot be used on a range or cooker top.
20. Never leave the empty glass carafe on the warming plate otherwise the glass carafe is liable to crack.
21. Do not clean glass carafe with cleansers, steel wool pads, or other abrasive materials.
22. To switch off and disconnect, turn control to off position and then remove plug from wall outlet. Always hold the plug, but never pull the cord.
23. Do not use appliance for anything other than its intended use and place it in a dry environment.

24. Never use the appliance if the glass carafe shows any signs of cracks or if the handle is loose or has been weakened in any way. Only use the glass carafe that comes with this appliance. Use carefully as the glass carafe is very fragile.
25. Do not place a hot glass carafe directly on to a worktop
26. Scalding may occur if the cover is removed during the brewing cycles.
27. Do not use outdoors.

APPLIANCE OVERVIEW



Before First Use

Check that all accessories are complete and the unit is not damaged. Add clean water up to maximum level to brew several times without ground coffee according to the steps opposite, and then discard the water. Wash the detachable parts thoroughly with warm water.

OPERATING INSTRUCTIONS

- Open the top cover and fill the water tank with cold drinking water. The water level should not exceed MAX level as indicated on the water gauge.
- Ensure the funnel and permanent filter is clean and fitted correctly.
- Add ground coffee, with the spoon provided, into the permanent filter. Usually a cup of coffee needs a level spoon of ground coffee. But you may adjust according to personal taste. Close the top cover.
- Insert the glass carafe on to the warming plate horizontally.
- Plug the power cord into the mains wall socket, ensuring it is switched on.
- Press the ON/OFF button. The indicator will be illuminated and the brewing process will commence.

Note: During the brewing process you may remove the glass carafe to serve. The coffee maker will stop dripping automatically. If the serve time exceeds 30 seconds, the coffee may overflow the funnel and filter.

- Upon completion of brewing the coffee, (approximately one minute after the coffee has stops dripping out) you can remove the glass carafe , pour and serve.

Note: The volume of brewed coffee will be slightly less than the water you have added to the tank, as water is absorbed by ground coffee. DO NOT touch the cover or the warming plate when operating as they are very hot.

- When the process is finished, if you do not want to serve immediately, leave the appliance switched on and the warming plate will keep coffee warm up to 40 minutes. The appliance will be cut off automatically after 40 minutes. For an optimum coffee taste, serve it just after brewing.
- Always turn the coffee maker off and disconnect the power supply after use.

Note: Be careful when pouring the coffee, as the coffee will be very hot and could cause scalding.

CLEANING AND MAINTENANCE

Caution: Always unplug the appliance from the manis wall socket and allow the warming plate to cool completely before cleaning it. Never immerse the unit or power cord in water or any other liquid for cleaning.

- Clean all detachable parts after each use in hot, soapy water.
- Wipe the exterior surface with a soft, damp cloth to remove stains.
- Water droplets may buildup in the area above the funnel and drip onto the product base during brewing. To control the dripping, wipe off the area with a clean, dry cloth after each use of the product.
- Use a damp cloth to gently wipe the warming plate. Never use abrasive cleaner to clean it.
- Replace all detachable parts

DESCALING YOUR APPLIANCE


To keep your coffee maker operating efficiently, periodically you should clean away the limescale left by the water according to the water quality in your area and the frequency of use. We recommend descaling your appliance as follows, using a solution of white vinegar and cold water. A solution of two tablespoons (30ml) white vinegar in one carafe of cold water works best.

- Fill the tank with the vinegar solution to the maximum level as indicated on water gauge.
- Insert glass carafe onto the warming plate.
- Ensure that the paper filter (without ground coffee) and funnel are assembled in place.
- Switch on the appliance and allow it to “brew” de-scaling solution.
- After “brewing” one cup of the solution, turn off the appliance.
- Leave the solution for 15 minutes and repeat step 3-5, until the water tank is completely empty.
- Rinse by operating the appliance with water at least 3 times.

HINTS FOR GREAT-TASTING COFFEE

- A clean coffee maker is essential for making great-tasting coffee. Regularly clean the coffee maker as specified in the “CLEANING AND MAINTENANCE” section. Always use fresh, cold water in the coffee maker.
- Store unused ground coffee in a cool, dry place. After opening a package of ground coffee, reseal it tightly and store it in a refrigerator to maintain its freshness.
- For an optimum coffee taste, buy whole coffee beans and finely grind them just before brewing.
- Do not reuse ground coffee as this will greatly reduce the coffee’s flavour. Reheating coffee is not recommended as coffee is at its peak flavour immediately after brewing.
- Clean the coffee maker when over-extraction causes oiliness. Small oil droplets on the surface of brewed, black coffee are due to the extraction of oil from the ground coffee.
- Oiliness may occur more frequently if heavily roasted coffees are used.

MAINS PLUG FUSE REPLACEMENT



Fuse Replacement (Class I)

This appliance must be earthed. Remove the central screw on the plug and open the shell. Take out the fuse and replace with a new fuse of the same Amp. Install the shell again and tighten the screws.

TROUBLE SHOOTING

Fault	Possible Cause	Solution
Appliance does not work.	Mains plug is not plugged in or is loose.	Insert mains plug.
	Fuse has blown or is defective.	Check fuse, replace if necessary.
	Socket is defective.	Mains malfunctions are to be corrected by an electrician.
Water not heating up.	Thermostat is broken.	Contact Igenix 01473 271 272, with product code and guarantee details.
Liquid found under the appliance.	Water tank may have a crack or the water tube has split or broken.	Contact Igenix 01473 271 272, with product code and guarantee details.
Condensation is forming on the appliance.	Condensation has gathered after continuous use.	Allow the appliance to cool down after each use.
Reduced or no liquid flow (only producing 3 cups when water tank is filled up to MAX level.)	Water tube has become blocked.	Appliance needs descaling, see “Cleaning and Maintenance” in the instruction manual
	Funnel has become blocked.	Check that the filter isn't damaged and allows lumps of coffee powder to form in the funnel.
Coffee powder is not dissolving properly.	Coffee powder has become damp and has formed clumps as condensation got into the powder.	Store coffee powder in an air tight container in a cool dark place to keep it dry. Only use dry coffee powder.
Making less cups of coffee than the water gauge says.	The coffee powder will soak up some of the water in filtration.	Initially add a little more water than the gauge says to allow for the short full, ensuring not to go over the maximum.
	Anti-drip valve at the bottom of funnel is not released.	Close glass jug lid. The lid should be closed before placing the jug in correct position.

DISPOSAL INFORMATION

The European Directive 2012/19/EU on Waste Electrical and Electronic Equipment (WEEE), requires that old household electrical appliances must not be disposed of in normal unsorted municipal waste.



Old appliances must be collected separately in order to optimise the recovery and recycling of the materials they contain and reduce the impact on human health and the environment.

The crossed out “wheeled bin” symbol on the product reminds you of your obligation, that when you dispose of the appliance it must be separately collected. Consumers should contact their local authority or retailer for information concerning the correct disposal of their old appliance.



Igenix Warranty Terms & Conditions

This product is guaranteed for a period of 12 months as standard from the date of purchase against mechanical and electrical defects. You can extend your warranty for a further 12 months by registering your product.

Upon registration we will cover your product for a period of 24 months from the original purchase date against any mechanical or electrical defects.

To qualify for the guarantee, the product must be used for domestic household use only and in accordance with the instructions in the user manual. Any misuse of the product will result in the warranty being void.

The guarantee does not cover accidental damage, misuse, neglect, tampering or incorrect adjustment or installation.

The guarantee will be rendered invalid if the product is resold, has had its serial number removed (or has an invalid serial number), or if an unauthorised person has carried out any repairs or alterations.

The warranty does not cover accessories or consumable parts that require replacement under normal use. This includes shelving, dials, filters, belts and trays etc.

In the unlikely event of a breakdown please refer to the Troubleshooting guide in your user manual and check all plugs, fuses and the electricity supply.

If you still require assistance please contact our Customer Service department on **01473 271 272** or write to us at the following address:

**Customer Service Department
38 Bluestem Road, Ransomes Europark
Ipswich, IP3 9RR**

Please quote the Product Code which begins 'IG' or 'DF' and the PO Number on the front of the instruction manual and give details of the exact fault. We will then decide whether to repair or replace the item.

Before we arrange the repair or replacement you will be required to return a copy of your proof of purchase. Please retain your original.

If an item is replaced within the agreed guarantee period, the guarantee for the replacement item will be calculated from the purchase date of the original.

In the event that the product is inspected and no fault is found or the product is not within the guarantee period you will be charged for the repair and any carriage costs.



Thank you for choosing Igenix

As a valued customer we would like to offer you a FREE 2 year warranty to cover your product against any electrical or mechanical defects.

This means that in the unlikely event you develop a fault or problem with your product we will happily repair or replace the item free of charge.

To qualify for the 2 year warranty you must register your product within 30 days of purchase. The full Terms & Conditions of our warranty policy are shown on the opposite page. They are also available on our website. **www.igenix.co.uk**

igenix

38 Bluestem Road, Ransomes Europark, Ipswich, IP3 9RR

Tel. 01473 271 272

Disclaimer: Igenix operate a policy of continual improvement and development.
We therefore reserve the right to change/alter the specification and appearance of our appliances without prior notice.
All diagrams and images shown in this manual are for illustration purposes only.