

## Smart Air Purifier White



**IG9600WIFI**

**Please read these instructions carefully before use and retain for future reference**

**Before switching on your appliance,  
always check for any damage which may have been caused in transit**

# CONTENTS

Safety Instructions.....	3-4
Technical Specifications.....	5
Appliance Overview .....	6
Filter Installation.....	7
Operating Instructions.....	8-9
Tips For Correct Use .....	9
Setting Up Wi-Fi Function.....	10-18
Cleaning and Maintenance .....	19
Troubleshooting.....	20
Fuse Replacement .....	21
Disposal Information .....	21
Igenix Warranty Information .....	22-23

## SAFETY INSTRUCTIONS

Carefully read the instructions before operating the unit. Please retain this manual for future reference.

**Important:** This product is intended for domestic and light office use **ONLY** and not for commercial, industrial or outdoor use.

When using electrical appliances, basic safety precautions should always be followed:


- All electrical repairs must be carried out by a qualified electrician. Inadequate repairs may result in a major source of danger for the user and invalidate the warranty.
- Do not operate the unit if the plug or cord is damaged, after it malfunctions or has been dropped or damaged in any way. It must be repaired by a qualified electrician.
- Make sure the unit is connected to an earthed power supply of the correct rating. Please refer to the rating label located at the side of the unit.
- Use of an extension cord is not recommended with this product.
- This unit should only be used by adults.
- Keep the unit and its cord out of reach of children.
- Children shall not play with the appliance.
- Cleaning and user maintenance shall not be made by children.
- The unit should not be used by persons with reduced physical, sensory or mental capabilities.
- It is not recommended to place this appliance in cupboards, closets, boats, caravans or similar locations.
- Do not use the unit in a wet room, such as a bathroom or laundry room or in areas where the unit is likely to get splashed.
- Always place unit on a dry and stable surface.
- Do not insert pencils or any other objects into the openings of the unit.
- Do not spray any flammable materials such as pesticides or perfumes around the product.

- Do not allow any liquid or any flammable detergent to get into the product. This is to avoid electric shocks and fire.
- Do not clean the unit by spraying it or immersing in water.
- Do not unplug the unit while it is working, as this could damage the electronic circuits.
- Always use the control panel to start and stop the unit.
- Always turn the unit off when not in use by removing the plug from the wall socket; making sure to pull on the plug top and not the cord.
- Always turn off the unit before cleaning, carrying out maintenance or moving location.
- Do not pull or place the electrical cable near a source of heat; always unroll it completely to avoid dangerous overheating.
- The filter must always be used with the product. When removing it for cleaning always turn the unit off and unplug from the mains wall socket.
- This product cannot replace normal ventilation, daily dust collection or oil pumping when cooking.
- Ensure the power cord plug is well connected with the power socket. If not, the plug will become hot.
- Leave at least 30cm of space all around the product, and at least 50cm of space above the product when using.
- Do not place the product under an air conditioner to prevent condensation water dropping into the product.
- Ensure both the filter and the back cover are properly installed before connecting to power source.
- Please only use and replace the filter specially designed for this product.
- Do not use hard objects to strike the products, especially the air outlet and air inlet.

## SPECIFICATION

<b>Model</b>	<b>IG9600WIFI</b>
Voltage (V)	220 - 240
Frequency (Hz)	50 - 60
Power (W)	50
Coverage Area (m <sup>2</sup> )	50
CADR (m <sup>3</sup> /h)	400
Air Flow (m <sup>3</sup> /h)	300
Filter Type	H13 HEPA
Filtration	3 Stage (pre-filter - activated carbon filter - HEPA filter)
Timer	2H / 4H / 8H
Fan Speed	Auto / High / Sleep
Noise Level (dB)	30 - 60
Product dimensions (mm)	H:532 x W:272 x D:302
Product weight (kg)	5 kg


# APPLIANCE OVERVIEW



\*Replacement H13 HEPA filter available - search for code IGAP0001 on the Igenix website:  
[www.igenix.co.uk](http://www.igenix.co.uk)

## FILTER INSTALLATION


**IMPORTANT:** Before use, ensure all packaging on the filter is removed. Always ensure the machine is unplugged before removing or installing the filter.



1. Press and hold the release button to remove the back cover.
2. Remove the filter from the machine.
3. Remove all packaging on the filter.
4. Insert the filter into the machine and ensure it's securely in place.
5. Replace the back cover onto the machine.

# OPERATING INSTRUCTIONS

## CONTROL PANEL



- |                               |                                     |
|-------------------------------|-------------------------------------|
| A. Wi-Fi                      | E. Change Filter Indicator          |
| B. Delay Timer (2H / 4H / 8H) | F. Anion/UV Function Indicator      |
| C. Sleep and High Mode        | G. PM2.5 Value (air quality rating) |
| D. Auto Mode                  |                                     |

### Light Indicator

- Red light emitted – air quality is poor; the machine is operating in a high mode.
- Yellow light emitted – air quality is average; the machine is operating in a standard mode.
- Blue light emitted – air quality is good; the machine is operating in a low mode.

### Modes and Button Operation

Plug in and switch on to connect the power; all indicators lights will flash on for 1 second. After that, the machine will go in standby mode.

#### Power Button



Press the Power button to turn on the machine. The unit will start up in Auto mode and the light indicator on the top of the machine will cycle through a series of colours (Blue - Cyan - Green - Yellow - Orange - Red – Purple) lasting around 30 seconds. During this preheating stage, the machine works in a High Mode and the value on the digital display is 00. After 30 seconds, the indicator light will be influenced by the air quality. (see 'Light Indicator' above).

The digital display will show the PM2.5 value according to the air quality.





### **Wind Speed Button**

Press the Wind Speed button to cycle through the different wind speed options (Auto – Sleep – High). Once the desired wind speed is selected the corresponding light will show on the digital display.



### **Sleep Mode**

This function is intended for night time use as it gradually reduces operation of the appliance before turning off. The lights are dimmed, and the noise level is reduced. If the unit is in Sleep Mode and the air quality is good (blue light emitted from the top of the unit) then the machine will turn off automatically after 5 seconds.

**Auto**

### **Auto Mode**

The wind speed will be automatically adjusted according to the air quality detected by the unit's laser sensor. The colour of the light emitted from the top of the unit will change according to the air quality.

**H**

### **High Mode**

The wind speed is on its strongest setting to assist in purifying the air more quickly.



### **Delay Timer / Wi-Fi Button**

To adjust the Delay Timer for the machine, press the Delay Timer button continuously to cycle through the options of 2 hours (2H), 4 hours (4H) or 8 hours (8H) until your preferred time is selected. The machine will then automatically turn off after the selected length of time.



### **UV / Anion Light Button**

When the machine is on, each time you touch the UV/Anion/Light button an alert will sound for 1 second and the light will switch between soft - standard - off

When the machine is on, press and hold for 5 seconds until the alert sounds, and then UV and Anion Function will be turned on. Press and hold for another 5 seconds until the alert sounds, UV and Anion will turn off.

## **TIPS FOR CORRECT USAGE**

**To get the best from your appliance, follow the below recommendations:**

- **Close all windows and doors in the room to be air purified**
- **Never rest objects of any kind on the appliance**
- **Do not block the air inlet or outlet of the appliance**
- **Reduced air flow will result in poor performance and could damage the unit**
- **Never use the appliance in very damp rooms**
- **Never use the appliance outdoors**
- **Make sure the appliance is standing on a level surface**
- **When not in use and switched off at the plug, cover the appliance to protect from dust. This will help the filter last longer**

# SETTING UP WI-FI FUNCTION

## 1. Setting up the Igenix app

- Download the Igenix app from Apple Store for IOS or from Google Play for android and install the app on your device.
- Register your new Igenix account and sign in to the app.

**NOTE: This product will only connect to 2.4GHz bandwidth. While most modern routers are dual bandwidth (both 5GHz and 2.4GHz) and will automatically select the correct one for individual WiFi compatible appliances, please try manually adjusting your router to 2.4GHz if struggling to connect.**

## 2. Pair the Air Purifier with the Igenix app

- Plug your IG9600WIFI into a power socket and leave it in the standby mode.
- Press and hold the Delay Timer button until it beeps and the Wi-Fi light symbol starts to flash.
- From the Igenix app choose 'add device.'
- Please then follow instructions on the screen. (small appliances - Air Purifier (Wi-Fi))

## Wi-Fi Troubleshooting

Description	Analysis of cause
Appliance can't be configured successfully	<ol style="list-style-type: none"> <li>1. Check the mobile connected WLAN router SSID and password is correct</li> <li>2. Check whether there are additional settings of WLAN router as shown below:               <ol style="list-style-type: none"> <li>a) Firewall by router itself or by PC</li> <li>b) MAC address filtering</li> <li>c) Hidden SSID</li> <li>d) DHCP server</li> </ol> </li> </ol> <p>Reboot WLAN router, mobile device and appliance (WLAN module) and connect appliance by CF mode again. Before rebooting, check nobody has already connected to same appliance</p>
Mobile can't control appliance	<ol style="list-style-type: none"> <li>1. When appliance (WLAN module) is rebooted and app displays device remove, ignoring this confirmation will lead to mobile device losing control permission of the appliance. You will need to connect the appliance by CF mode again</li> <li>2. In case of power failure, mobile device will lose control permission of appliance for 3 minutes after power failure (Notification will now show up on the mobile device)</li> </ol> <p>If you cannot control the app (appliance) even after power restored, you will need to connect the appliance by CF mode again.</p>
Mobile can't find the appliance	<ol style="list-style-type: none"> <li>1. App display appliance Device online. Please check the following conditions:               <ol style="list-style-type: none"> <li>a) The appliance has been reconfigured</li> <li>b) Appliance out of power</li> <li>c) Router out of power</li> <li>d) Appliance can't connect to router</li> <li>e) Appliance can't connect to network through the router</li> <li>f) Mobile device can't connect to network</li> </ol> </li> <li>2. After adding the device, it disappears in device list. Hold and slide down to refresh the device list. If it has no change, shut down the app and start again.</li> </ol>

- Once the device configuration is successful you then have the option to rename your device.  
**Note: In order to successfully sync with your Amazon Echo, it is advised that you rename your device to an easily recognised word or phrase, such as “Air Purifier”, as this will have a much greater compatibility with Alexa.**




fig.1

## SYNCING DEVICE WITH AMAZON ALEXA

### I. Set up Amazon Echo and enable Igenix app

- Search the “Amazon Alexa” app on the Apple Store for IOS, or on Google Play for Android, and install the app to your device.

### 1a. Set up Echo with Alexa app

**Note: You will need to purchase an Amazon Echo device to utilise this functionality. If you already have an Echo device that is set up you can skip this step.**

- Plug your Echo device (Echo, Echo Tap or Echo Dot) into a power socket and turn it on.
- Make sure your Echo device is energized.
- Open the Alexa app by tapping the app icon on your mobile device.
- Register for an Amazon account, if you don't have one, or enter your Amazon account and password, then tap "sign in" (fig.2)




fig.2

- Select the "Menu" option in the top left corner (fig.3), select "Settings" (fig.4), then tap "SET UP A NEW DEVICE" (fig.5).




fig.3




fig.4




fig.5

- Select your Echo device (fig.6), choose the appropriate language (fig.7), and then tap “CONNECT TO WI-FI” (fig.8)



fig.6




fig.7



fig.8

- Hold down the dot button on the top of your Echo device until the orange light shows up (fig.9), and then tap “CONTINUE”.When your device is connected to Echo, tap “CONTINUE” (fig.10-11)



fig.9




fig.10




fig.11

- Select a Wi-Fi network to let Echo access the Internet (fig.12). Type in the Wi-Fi password and then tap “CONNECT” (fig.13). Echo may take several minutes to connect to the network (fig.14).



fig.12




fig.13



fig.14

- Tap “CONTINUE” when Echo is connected to the network (fig.15). After an introduction video, tap “NEXT” to finish the setup (fig.16)



fig.15



fig.16

## Ib. Link Igenix app account to Alexa app

- Select the “Menu” option in the top left corner and select “Skills” (fig.17), and then search “Igenix” in the search bar (fig.18).
- Select “Igenix” and tap “ENABLE” to enable the skill.




fig.17




fig.18

- You will be redirected to the account link page.
- Type in your Igenix account and password and then tap “Link Now” to link your Igenix account (fig.19)

**Note: The country, the account and the password must match the exact content in step 2.**




fig.19



## 2. Control your Air Purifier through Amazon Echo

### 2a. Discover your IG9600WIFI device

- Echo needs to discover your smart devices before it controls them.
- You can say “Alexa, discover devices” to Echo. Then Echo will discover devices that have already been added in the Igenix app.
- Alternatively, you can select in the “Menu” option “Smart Home” (fig.20) and then tap “DISCOVER” to discover the smart devices (fig.21). Discovered devices will be shown in the list (fig.22).

**Note: Every time you change the device’s name in the Igenix app, Echo must rediscover before you can control them.**




fig.20



fig.21




fig.22

## **CONTROL YOUR AIR PURIFIER BY VOICE COMMANDS**

Now you can control your Igenix device through Echo. You can use the following commands to control your Air Purifier:

### **To Turn on Power:**

“Alexa, turn on AIR PURIFIER.”

“Alexa, turn off AIR PURIFIER.”

### **To Choose Mode:**

“Alexa, set AIR PURIFIER to <Mode: Sleep/H/Auto>”

“Alexa, what is the mode on AIR PURIFIER?”

### **To Turn on Night light:**

“Alexa, turn on light on the AIR PURIFIER.”

“Alexa, turn off light on the AIR PURIFIER.”

“Alexa, is light on for AIR PURIFIER?”

### **To Turn on Anion:**

“Alexa, turn on anion on the AIR PURIFIER.”

“Alexa, turn off anion on the AIR PURIFIER.”

### **To Turn on UV:**

“Alexa, turn on UV on AIR PURIFIER.”

”Alexa, turn off UV on AIR PURIFIER.”

# CLEANING & MAINTENANCE

Before any cleaning or maintenance, turn the appliance off on the control panel or via your smart device. Wait for a few minutes then unplug from the mains socket.

## Filter Replacement Indicator

- To keep your appliance working efficiently, the machine automatically detects when the filter is saturated and needs to be replaced. After running for 2200 working hours, the replacement filter indicator light will continuously flash red
- To replace the filter, please follow the instructions outlined in the FILTER INSTALLATION section of the instruction manual
- **NOTE: Ensure that you are using the specially designed H13 HEPA filter supplied by Igenix. These filters are available by searching for code IGAP0001 on the igenix website ([www.igenix.co.uk](http://www.igenix.co.uk))**
- Once the new filter has been correctly installed into the unit, press and hold the Wind Speed button for 7 seconds to turn off the flashing red light

## IMPORTANT:

- Change for a clean filter when indicator dictates
- Do not wash or reuse the filter
- Do not use a vacuum cleaner to clean the filter or wash it directly
- Ensure the machine is unplugged before replacing the filter
- Please sterilize the filter under sunlight regularly

## Cleaning and Storage

- Ensure the machine is unplugged before carrying out any maintenance
- Do not immerse the air purifier in water or use any liquid for cleaning
- Do not use abrasive, corrosive or flammable cleansers (such as bleach or alcohol) to clean any part of the unit
- Do not drop any water into the machine when cleaning the air outlet

## How to Clean

- Ensure the machine is turned off and unplugged from the power socket
- Take out the filter to clean and remove any dust from the appliance
- Use a soft cloth with neutral cleanser to clean away any dust or debris from the surface of the machine
- After the filter is air dried, re-install back into the air purifier before restarting
- If you do not use the machine for a long time, ensure the machine is dried out, the dust cover is placed over it and it is stored in a cool, well-ventilated location

## TROUBLE SHOOTING GUIDE

If you experience difficulties with the appliance, please check the suggestions below before contacting customer services:

Problem	Solution
Appliance isn't working	<ul style="list-style-type: none"><li>• It isn't plugged into a power socket</li><li>• There is a power outage</li><li>• The home leakage switch or fuse is cut off</li><li>• The filter replacement indicator keeps flashing, meaning the filter needs to be replaced urgently</li></ul>
The appliance is performing poorly	<ul style="list-style-type: none"><li>• There is a large amount of dust built up on the surface of the primary filter</li><li>• There are obstacles blocking the air inlet/outlet</li></ul>
The appliance is making a significant noise	<ul style="list-style-type: none"><li>• There is an object stuck on the fan in the air outlet</li><li>• The machine is not sat on a level surface</li><li>• The wind speed is on the High setting (reduce the wind speed setting if the noise is obtrusive and the high speed performance is not required)</li></ul>
A nasty smell is being emitted from the appliance	<ul style="list-style-type: none"><li>• It is the normal phenomenon that the machine emits the smell of plastic when used for the first time</li><li>• The machine will emit a nasty smell if the filter is dusty, so in this situation, please clean or replace the filter</li><li>• If a burning smell is being emitted from the machine, unplug the unit from the power socket immediately and contact customer service</li></ul>
The Filter Replacement Indicator is still flashing after the filter has been replaced	<ul style="list-style-type: none"><li>• Press the wind speed button for 7 seconds to reset the machine and the indicator light will switch off</li></ul>

**WARNING: If the above troubleshooting tips cannot solve your problem and your unit requires further maintenance, please contact the supplier or customer service. Please do not disassemble the machine to maintain by yourself.**

## MAINS PLUG FUSE REPLACEMENT

### Fuse Replacement (Class I)

This appliance must be earthed. Remove the fuse cover with a small flat head screw driver. Take out the fuse and replace with a new fuse of the same Amp. Replace the fuse cover and push back into place.



## DISPOSAL INFORMATION

The European Directive 2012/19/EU on Waste Electrical and Electronic Equipment (WEEE), requires that old household electrical appliances must not be disposed of in normal unsorted municipal waste.

Old appliances must be collected separately in order to optimise the recovery and recycling of the materials they contain and reduce the impact on human health and the environment.

The crossed out “wheeled bin” symbol on the product reminds you of your obligation, that when you dispose of the appliance it must be separately collected. Consumers should contact their local authority or retailer for information concerning the correct disposal of their old appliance.



## Igenix Warranty Terms & Conditions

This product is guaranteed for a period of 12 months as standard from the date of purchase against mechanical and electrical defects. You can extend your warranty for a further 12 months by registering your product.

Upon registration we will cover your product for a period of 24 months from the original purchase date against any mechanical or electrical defects.

To qualify for the warranty, the product must be used for domestic household use only and in accordance with the instructions in the user manual. Any misuse of the product will result in the warranty being void.

The warranty does not cover accidental damage, misuse, neglect, tampering or incorrect adjustment or installation.

The warranty will be rendered invalid if the product is resold, has had its serial number removed (or has an invalid serial number), or if an unauthorised person has carried out any repairs or alterations.

The warranty does not cover accessories or consumable parts that require replacement under normal use. This includes shelving, dials, filters, belts and trays etc.

In the unlikely event of a breakdown please refer to the Troubleshooting guide in your user manual and check all plugs, fuses and the electricity supply.

If you still require assistance please contact our Customer Service department on **01473 271 272** or write to us at the following address:

**Customer Service Department  
38 Bluestem Road, Ransomes Europark  
Ipswich, IP3 9RR**

Please quote the Product Code which begins 'IG' or 'DF' and the PO Number on the front of the manual, and give details of the exact fault. We will then decide whether to repair or replace the item.

Before we arrange the repair or replacement you will be required to return a copy of your proof of purchase. Please retain your original.

If an item is replaced within the agreed warranty period, the warranty for the replacement item will be calculated from the purchase date of the original.

In the event that the product is inspected and no fault is found or the product is not within the warranty period you will be charged for the repair and any carriage costs.



## **Thank you for choosing Igenix**

As a valued customer we would like to offer you a FREE 2 year warranty to cover your product against any electrical or mechanical defects.

This means that in the unlikely event you develop a fault or problem with your product we will happily repair or replace the item free of charge.

To qualify for the 2 year warranty you must register your product within 30 days of purchase. The full Terms & Conditions of our warranty policy are shown on the opposite page. They are also available on our website. **[www.igenix.co.uk](http://www.igenix.co.uk)**



38 Bluestem Road, Ransomes Europark, Ipswich, IP3 9RR  
EU: Castle Electrical Factors Ltd., Dundalk, A91 KA9R, IR  
Tel. 01473 271 272

Disclaimer: igenix operate a policy of continual improvement and development.  
We therefore reserve the right to change/alter the specification and appearance of our appliances without prior notice.  
All diagrams and images shown in this manual are for illustration purposes only.